

Left & Right Speakers

Model 932 Speaker Modules can be configured to function as left, right or mono modules. The slide switch on the bottom left side of the module is marked "LEFT-RIGHT." Position the switch to "LEFT" for left channel function and RIGHT for either right channel or MONO function. (If used for mono operation there will not be a corresponding "L" module.)

932 modules in the Front Speaker Product Group are unique in the fact that they share the same GROUP Address with the receiver group. For example, if the Receiver Product Group number is "4", then the Front Speaker Group number would also be "4". All other speaker groups should have a higher GROUP address.

LEFT and RIGHT modules have the same Module ID (e.g. for front speakers 1-8 both LEFT & RIGHT modules would be addressed: MODULE ID= "0-9" on the slide switch, and "0" on the rotary switch; GROUP= 4. The next module pair for front speakers 9-16 both LEFT & RIGHT modules would be addressed: MODULE ID= "0-9" on the slide switch, and "1" on the rotary switch; GROUP= 4, etc.)

